



CB IDEAL TAPWARE Pty Ltd

ABN: 98 156 625 035 ACN: 156 625 035

1A Deloraine Road, Edwardstown SA 5039

PH: (08) 8276 6766 FAX (08) 8276 6623

EMAIL: cbideal@cbideal.com.au WEB: www.cbideal.com.au

Installation Instructions – Alcove Shower Set



In wall requirements – 2 x 1/2" male threads at 150mm centres

1. Take angle taps from set as supplied, install pressed flanges and taps on to in-wall threads (use thread tape) with outlets of taps pointing upwards.
2. Fit nuts and olives on to breeching piece, tighten nuts down on to outlets of taps in 1) above.
3. Install pillarclip on wall at a suitable point vertically above centre thread on breeching piece connection, to hold shower riser tube.
4. Screw shower arm (with rose) on to threaded end of shower riser.
5. Fit shower riser (with nut and olive) to centre thread on breeching piece (use thread tape). The shower riser tubing can be cut to the desired height.
6. Fit shower riser tube in to pillarclip and tighten. BEWARE – riser tube is easily scratched if pillarclip is not fully open.

IMPORTANT

Maximum hot water temperature 80°C and 500 kPa Maximum operating pressure at any outlet within a building (Ref AS/NZS 3500)

WARRANTY

The Company accepts responsibility for any fault due to the Company's own workmanship or materials except for subjective variations or random unavoidable blemishes of a minor non-functional nature. This acceptance of responsibility is for 12 months from the date of installation, proof of which may be required.